



TROLLEY JACK 2 TONNE SHORT CHASSIS WITH STORAGE CASE

MODEL NO: **1100CXD.V5**

Thank you for purchasing a Sealey product. Manufactured to a high standard, this product will, if used according to these instructions, and properly maintained, give you years of trouble free performance.

IMPORTANT: PLEASE READ THESE INSTRUCTIONS CAREFULLY. NOTE THE SAFE OPERATIONAL REQUIREMENTS, WARNINGS & CAUTIONS. USE THE PRODUCT CORRECTLY AND WITH CARE FOR THE PURPOSE FOR WHICH IT IS INTENDED. FAILURE TO DO SO MAY CAUSE DAMAGE AND/OR PERSONAL INJURY AND WILL INVALIDATE THE WARRANTY. KEEP THESE INSTRUCTIONS SAFE FOR FUTURE USE.




Refer to instructions



Wear safety footwear

1. SAFETY

- ✓ Ensure the jack is in sound condition and good working order. Take action for immediate repair or replacement of damaged parts. *Use genuine parts only. The use of unapproved parts may be dangerous and will invalidate the warranty.*
 - ✓ Locate the jack in a suitable, well lit working area.
 - ✓ Keep working area clean and tidy and free from unrelated materials.
 - ✓ Use jack on level and solid ground, preferably concrete. Avoid tarmac as jack may sink in.
 - ✓ Place chocks under wheels of vehicle (but ensure wheels of jack can move freely).
 - ✓ Ensure the vehicle's handbrake is engaged, the engine is switched off and transmission is in gear (or "PARK" if automatic).
 - ✓ Ensure minimum distance of 0.5m between vehicle and static objects such as doors, walls, etc., to allow for vehicle tilting.
 - ✓ Ensure there are no passengers in the vehicle.
 - ✓ Ensure all non-essential persons keep a safe distance whilst the jack is in use.
 - ✓ Only place jack under vehicle manufacturer's recommended lifting points (*see vehicle handbook*).
 - ✓ Check the lifting point is stable and centred on the jack saddle.
 - ✓ Ensure the jack wheels are free to move and that there are no obstructions.
 - ✓ Use correctly rated axle stands under the vehicle before proceeding with any task.
 - ✓ Ensure there are no persons or obstructions beneath the vehicle before lowering.
 - ✓ Use a qualified person to maintain or repair the jack hydraulic system.
 - ✓ When not in use, store jack, fully lowered, in a safe, dry, childproof area.
- IMPORTANT!** During the jacking operation, ensure that the vehicle-to-jack saddle contact point are always visible.
- ▲ **DANGER!** Use the jack for lifting only, **NOT** for supporting the lifted load.
 - x **DO NOT** operate the jack if damaged.
 - x **DO NOT** allow untrained persons to operate the jack.
 - x **DO NOT** exceed the rated capacity (2 tonne) of the jack.
 - x **DO NOT** allow the vehicle to move while supported by the jack, or use the jack to move the vehicle.
 - x **DO NOT** jack vehicle if there is a risk of spillage of fuel, battery acid, or other dangerous substances.
 - x **DO NOT** work under the vehicle until suitably rated axle stands have been correctly positioned.
 - x **DO NOT** use the jack for purposes other than which it is intended.
 - x **DO NOT** top up hydraulic system with brake fluid. Use hydraulic jack oil only.
 - x **DO NOT** adjust the safety overload valve.



2. INTRODUCTION

Steel chassis with welded castor supports and one-piece hydraulic unit. Fitted with overload valve and finger cover for extra safety. At just 11.3kg this unit is ideal for the serious enthusiast or as an emergency mobile jack. Includes an integral carry handle and one-piece pumping handle. Supplied in tough carry/storage case to keep dirty jack away from contents of car boot.

3. SPECIFICATION

Model No:.....**1100CXD.V5**
 Capacity:..... 2tonne
 Length:..... 531mm
 Maximum Chassis Height:..... 132mm
 Maximum Saddle Height:..... 380mm
 Minimum Saddle Height:..... 130mm
 Nett Weight:..... 12.1kg

4. OPERATION

4.1. BEFORE FIRST USE

- 4.1.1. Before using jack for the first time, purge the hydraulic unit in order to eliminate any air in the system. Place handle (fig.2H) onto the release valve (fig.2B) and open valve by turning the handle anti-clockwise, place handle back into the jacking point (fig.2A) and pump 20 times. When complete, close the release valve by turning the valve (fig.2B) clockwise.
- 4.1.2. Place a few drops of hydraulic jack oil on pump piston and pump handle several times to distribute oil. Thoroughly lubricate moving parts.

NOTE: If your model is supplied with a plastic carrying handle fit it over the frames central nuts (fig.1A).

4.2. GENERAL JACKING




- WARNING!** Before lifting ensure section 1 safety instructions are read and understood.
 - WARNING!** When lifting at the jack's maximum rating (2 tonne) or close to it, it is recommended that the effort of raising the load shall be reduced by the assistance of a second person during this operation.
- 4.2.1. Prepare the vehicle as mentioned in the safety instructions ensuring the ground on which the jack is to stand is level and solid (not tarmacadam).
- 4.2.2. Position the jack saddle under the vehicle manufacturer's recommended lifting point.

4.3. JACKING THE VEHICLE

- 4.3.1. Place the handle onto the release valve (fig.2B) and turn it clockwise to close the valve. Place handle into socket (fig.2A) and commence pumping handle up and down using maximum strokes until the jack saddle reaches the vehicle jacking point. Check the jacking point is centrally located on the saddle and raise the vehicle.
- 4.3.2. Should the jack become overloaded, a safety excess pressure valve will open and stop the vehicle from lifting.
- WARNING!** The jack is a lifting device only and must not be used to support the load. Use correctly rated axle stands to support load.

4.4. LOWERING THE VEHICLE

- 4.4.1. If using axle stands, raise the jack high enough for the stands to be easily removed. Then place handle on release valve (fig.2B) and turn anti-clockwise, very slowly, to open the valve.
- 4.4.2. The lowering speed is controlled by the amount you turn the handle. Lower carefully, avoid any sudden changes in descent rate which may shock load the hydraulic system.
- WARNING!** Ensure there are no persons or obstacles beneath the vehicle, or in the path of its descent.



5. MAINTENANCE

- 5.1. When the jack is not in use, the ram should be in its lowest position to minimise corrosion. Remove the handle to inactivate jack.
- 5.2. Keep the jack clean and lubricate all moving parts with oil on a regular basis.
- 5.3. Before each use check for broken, cracked, bent, or loose parts, or any visible damage to ram, pump, saddle, lifting arm, frame and all parts including nuts, bolts, pins and other fasteners. If any suspect item is found remove jack from service and take necessary action to remedy the problem.
- × **DO NOT** use the jack if believed to have been subjected to abnormal load or shock load.
- 5.4. Periodically check the pump piston and the ram for signs of corrosion. Clean exposed areas with a clean oiled cloth.
- 5.5. After one year the oil should be replaced in order to extend the life of the jack. Use hydraulic jack oil only.
- NOTE:** Only fully qualified personnel should attempt hydraulic maintenance or repair.
- 5.6. To check the oil level, fully lower the jack. Remove front cover plate (fig.2C) and filler plug (fig.3O). The correct level is the bottom of the screw hole. If oil level is low, fill as required. Pump jack 5 or 6 times to expel air. Pump jack up to full height and pour off excess oil before refitting plug. **DO NOT** touch the safety overload valve (fig.3V)
- NOTE:** Use a good quality jack oil, such as SEALEY HYDRAULIC JACK OIL.
- WARNING: DO NOT** use brake fluid, or any fluid other than hydraulic jack oil as this may cause serious damage to the jack and will invalidate the warranty!
- 5.7. To drain the oil, remove the filler plug and raise front of jack. Make sure that no dirt is allowed to enter the hydraulic system.
- IMPORTANT:** NO RESPONSIBILITY IS ACCEPTED FOR INCORRECT USE OF THIS PRODUCT.
- Hydraulic products are only repaired by local service agents. We have service/repair agents in all parts of the UK.
- × **DO NOT RETURN JACKS TO US.** Please telephone us on 01284 757500 to obtain the address and 'phone number of your local agent. If jack is under guarantee contact your local Sealey stockist.
- 5.8. **DE-COMMISSIONING THE JACK**
- Should the jack become completely unserviceable and require disposal, draw off the oil into an approved container and dispose of the jack and the oil according to local regulations.

6. TROUBLE SHOOTING

PROBLEM	POSSIBLE CAUSE	REMEDY
Refer to item 4.1 and follow instructions for purging the hydraulic circuit		
Jack will not lift the load	1) Overloaded 2) Oil level low 3) Release valve not correctly closed 4) Air in system 5) Piston rod not functioning 6) Packing worn or defective	1) Be sure to use jack with adequate capacity 2) Top up oil level 3) Check and close release valve 4) Open release valve and pump the handle a few times Close valve and re-try 5) Clean and replace oil 6) Replace packing or contact local service agent
Jack does not lift high enough or feels 'spongy'	1) Oil level too high or too low 2) Worn seals 3) Air in system 4) Release valve not closed	1) Fill or remove excess oil 2) Return jack to local service agent 3) Open release valve and pump the handle a few times Close valve and re-try 4) Check and close release valve
Jack lifts poorly	1) Pump packing or valves malfunctioning 2) Oil is dirty 3) Air in the system	1) Replace packing and/or clean valves 2) Replace oil 3) Open release valve and pump the handle a few times Close valve and re-try
Jack lifts but will not hold load	1) Release valve partially open 2) Dirt on valve seats 3) Air in system 4) Faulty seals 5) Packing worn or defective	1) Check and close release valve 2) Lower jack, close release valve. Place foot on front wheel and pull up lifting arm to it's full height by hand. Open the release valve to lower arm 3) Open release valve and pump the handle a few times Close valve and re-try 4) Replace packing or contact local service agent 5) Replace packing
Jack will not lower completely	1) Unit requires lubrication 2) Piston rod bent or damaged 3) Jack frame/link system distorted due to overloading/poor positioning 4) Air in system 5) Release valve partially closed 6) Jack spring damaged or unhooked	1) Oil all external moving parts 2) Replace rod or contact local service agent 3) Replace damaged parts or contact local service agent 4) Open release valve and pump the handle a few times Close valve and re-try 5) Check and fully open release valve 6) Replace spring or contact local service agent
Jack does not lower at all	1) Release valve closed	1) Check and fully open release valve



ENVIRONMENT PROTECTION

Recycle unwanted materials instead of disposing of them as waste. All tools, accessories and packaging should be sorted, taken to a recycling centre and disposed of in a manner which is compatible with the environment. When the product becomes completely unserviceable and requires disposal, drain any fluids (if applicable) into approved containers and dispose of the product and fluids according to local regulations.

Note: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice.

Important: No Liability is accepted for incorrect use of this product.

Warranty: Guarantee is 12 months from purchase date, proof of which is required for any claim.

Sealey Group, Kempson Way, Suffolk Business Park, Bury St Edmunds, Suffolk. IP32 7AR



01284 757500



01284 703534



sales@sealey.co.uk



www.sealey.co.uk