



Item	Part No.	Description
1	SA11.V4-01	Housing
2	SA12S.V4-02	Sealing Valve
3	SA12S.V4-03	Valve Plate
4	SA12S.V4-04	Sealing Valve Cover
5	SA11.V4-05	Piston
6	SA11.V4-06	Cylinder
7	SA12S.V4-07	Spring
8	SA12S.V4-08	Trigger

Item	Part No.	Description
9	SA12S.V4-09	Straight Pin
10	SA12S.V4-10	Throttle Valve
11	SA12S.V4-11	O- Ring
12	SA12S.V4-12	Adjusting Valve Pole
13	SA12S.V4-13	Pin
14	SA12S.V4-14	Gas Admittance Valve
15	SA12S.V4-15	Taper Spring
16	SA28.V2-32	Air Inlet Connector

**NOTE:** It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice. There may be alternative versions of this product, please contact us should you require this information.

**IMPORTANT:** No liability is accepted for incorrect use of product. Spare parts must be fitted by a competent person

**WARRANTY:** Guarantee is 12 months from purchase date, proof of which will be required for any claim.