


DRAPER[®]

230V 340mm

BANDSAW

84715 – BS340/1100D SPARE PARTS DRAWING





BANDSAW

KEY No.	PART No.	STOCK No.	DESCRIPTION
1 – 6	YBS340/1100D-3A	98636	Blade tension knob assembly
7	YBS350D-07	21557	Frame cap
8 – 12	YBS340/1100D-10A	98638	Fittings assembly #1
13 – 21	YBS340/1100D-13A	98640	Fittings assembly #2
22 – 30	YBS340/1100D-25A	98641	Pulling plate assembly
31 – 35	YBS340/1100D-33A	98642	Upper / lower wheel assembly
36			Blade
37 – 42	YBS340/1100D-37A	98643	Upper cover assembly
43 – 46	YBS340/1100D43A	98644	Lower cover assembly
47 – 66	YBS340/1100D-62A	98645	Switch box assembly
67			(NP) Frame
68 – 73	YBS340/1100D-72A	98647	Brush assembly
74 – 76	YBS340/1100D-75A	98648	Spindle pulley assembly
77 – 82	YBS340/1100D-78A	98649	Drawer assembly
83 – 86	YBS340/1100D-85A	98650	Switch assembly
87 – 93	YBS340/1100D-92A	98651	Release handle assembly
94 – 96	YBS305-94A	98618	Tracking assembly
97 – 101 & 105 – 107	YBS340/1100D-98A	98652	Protecting cover assembly
102 – 104	YBS305-102A	98620	Adjusting knob assembly
108 – 123	YBS340/1100D-121A	98653	Upper guide block assembly
124			(NP) Socket head screw
125			(NP) Cover lock knob
126			(NP) Guide plate
127			(NP) Lock nut
128			(NP) Set screw
129			(NP) Flat washer
130			(NP) Hex head bolt
131			(NP) Cord bushing
132			(NP) Limiting shaft
133			(NP) Hex nut
134			(NP) Guide block
135			(NP) Lower guard
136			(NP) Hex head bolt
137			(NP) Flat washer
138			(NP) Shaft
139			(NP) Hex nut

[illegible]