


05531 - Chargestar P32

Exploded Diagram & Parts List



Ref. No.	Description	SIP Part No.	Ref. No.	Description	SIP Part No.
1.	Handle	PW02-00082	9.	Red cable	PW02-00054
2.	Cover	PW02-00084	10.	Red/Black clamps	PW02-00070
3.	Chassis	PW02-00115	11.	Black cable	PW02-00062
4.	Transformer	PW02-00045	12.	Mains lead	PW02-00111
5.	Rectifier	PW02-00031	13.	Fuse 5x20 T2.5a 250v	PW02-00002
6.	Ammeter 15a	PW02-00014	14.	Switch 16a	PW02-00020
7.	Circuit breaker 13a	PW02-00026	15.	Fuse holder	PW02-00009
8.	Cable gland	PW02-00078	16.	High/Low switch 16a	PW02-00021