



| Ref. No. | Description | SIP Part No. | Ref. No. | Description | SIP Part No. |
|----------|-----------------------|--------------|----------|---------------------|--------------|
| 1. | Handle | PW02-00082 | 9. | Black cable | PW02-00063 |
| 2. | Cover | PW02-00084 | 10. | Red/Black clamps | PW02-00071 |
| 3. | Cover for fuse holder | PW02-00011 | 11. | Red cable | PW02-00055 |
| 4. | Fuse 80a | PW02-00003 | 12. | Mains lead | PW02-00111 |
| 5. | Fuse holder | PW02-00010 | 13. | On/Off switch | PW02-00022 |
| 6. | Rectifier | PW02-00032 | 14. | High/Low switch 16a | PW02-00021 |
| 7. | Ammeter 20a | PW02-00015 | 15. | Transformer | PW02-00046 |
| 8. | Cable gland | PW02-00079 | 16. | Chassis | PW02-00090 |