




Ref. No.	Description	SIP Part No.	Ref. No.	Description	SIP Part No.
1.	Handle	PW02-00083	15.	Transformer	PW02-00052
2.	Ammeter 50A/start	PW02-00018	16.	Lower panel	PW02-00100
3.	Orange pilot lamp	PW02-00040	17.	Rear panel	PW02-00103
4.	Green pilot lamp	PW02-00041	18.	Red/Black clamps	PW02-00073
5.	Timer knob	PW02-00043	19.	Black cable	PW02-00068
6.	Timer	PW02-00042	20.	Cable gland	PW02-00081
7.	Switch knob	PW02-00024	21.	Fuse 200a	PW02-00007
8.	Front frame (plastic)	PW02-00098	22.	Fuse cover	PW02-00012
9.	Switch 12a sch9387	PW02-00023	23.	Front cover	PW02-00088
10.	Front panel	PW02-00094	24.	Red cable	PW02-00060
11.	Mains lead	PW02-00114	25.	Axle D16 L447	PW02-00108
12.	Dinse socket 25sqmm	PW02-00105	26.	Dinse plug 25sqmm	PW02-00106
13.	Thermostat (rectifier)	PW02-00027	27.	Wheel D175	PW02-00110
14.	Rectifier PMS12/2/2	PW02-00036	N/A.	Wheel clip	PW02-00144