



SIP 25137 Medusa T5500W Engine Driven Generator


General layout




1-Fuel tank



2-Frame:



3 - Control Panel




Item	Description	SIP Code
	1 - Fuel tank	
1	25L Fuel Tank	PW01-01702
2	Rubber Gasket	PW01-01703
3	Washer	PW01-01704
4	Flange Bolt M6×20	PW01-01705
5	Fuel Tank Cap	PW01-01706
6	Filter Tank Filter net	PW01-01707
7	Bolt M5×12	PW01-01708
8	Fuel Gauge	PW01-01709
9	Fuel Tap	PW01-01710
	2 - Frame	
10	Frame	PW01-01711
11	Cross Beam	PW01-01712
12	Flange Bolt M6×40	PW01-01713
13	Flange Nut M6	PW01-01714
14	Handle	PW01-01715
15	Anti Vibe Mount	PW01-01716
16	Supporting Legs	PW01-01717
17	Rubber feet	PW01-01718
18	Flange self-locking nut M12	PW01-01719
19	Plastic wheels	PW01-01720
20	Battery	PW01-01721
21	Shaft fixed bracket	PW01-01722
22	Flange Bolt M8×16	PW01-01723
23	Flange Nut M8	PW01-01724
24	Long shaft	PW01-01725
25	Rear Guard plate	PW01-01726
26	Flange Bolt M6×12	PW01-01727
27	Side Guard plate	PW01-01728

Item	Description	SIP Code
	3 - Control Panel	
28	Inlet Cable	PW01-01729
29	Panel body	PW01-01730
30	AC Breaker	PW01-01731
31	Bolt M6x 16	PW01-01732
32	Earth bolt	PW01-01733
33	Toggle Switch	PW01-01734
34	AC socket (230v)	PW01-01735
35	AC socket breaker	PW01-01736
36	Bolt M4×1	PW01-01737
37	AC socket (115v)	PW01-01738
38	DC Terminal	PW01-01739
39	Voltmeter	PW01-01740
40	Front Metal Panel	PW01-01741
41	On / OFF Switch	PW01-01742
42	Bolt M3×8	PW01-01743
43	DC Breaker	PW01-01744
44	Self tapping screw M4×12	PW01-01745
45	Bridge Rectifiers	PW01-01746

4 - Engine

5 - Alternator



Item	Description	SIP Code
	4 - Engine	
1	Flange Bolt M6×8	PW01-01747
2	Recoil starter	PW01-01748
3	Flange Bolt M6×12	PW01-01749
4	Fan Cover	PW01-01750
5	Flywheel Nut M16×1.5	PW01-01751
6	Starting Dog	PW01-01752
7	Fan	PW01-01753
8	Flywheel	PW01-01754
9	Governor Pull Rod	PW01-01755
10	Small Governor Spring	PW01-01756
11	Governor Arm	PW01-01757
12	Governor Spring	PW01-01758
13	Square Bolt M6×21	PW01-01759
14	Flangel Nut M6	PW01-01760
15	Governor Lever	PW01-01761
16	Governor jump ring	PW01-01762
17	Governor Base Plate	PW01-01763
18	Oil seal	PW01-01764
19	Crankcase	PW01-01765
20	Drain Plug	PW01-01766
21	Drain Plug Gasket	PW01-01767
22	Crankcase Pin φ8×14	PW01-01768
23	Camshaft	PW01-01769
24	Bearing 6207	PW01-01770
25	Bearing 6202	PW01-01771
26	Oil Sensor	PW01-01772
27	Flange Bolt M6×12	PW01-01773
28	Crankshaft	PW01-01774
29	Connecting Rod Cover	PW01-01775
30	Connecting Rod Bolt	PW01-01776

Item	Description	SIP Code
	4 - Engine..cont.	
31	Balance shaft	PW01-01777
32	Governor Cover	PW01-01778
33	Retainer Ring	PW01-01779
34	Governor Shaft	PW01-01780
35	Governor Gear	PW01-01781
36	Crankcase Gasket	PW01-01782
37	Dip Stick	PW01-01783
38	Dip Stick Seal	
39	Upper Crankcase cover	PW01-01784
40	Dust Filter	PW01-01785
41	Flange Bolt M8×35	PW01-01786
42	Connecting rod body	PW01-01787
43	Flywheel key	PW01-01788
44	Injector	PW01-01789
45	Gudgeon pin clip	PW01-01790
46	Gudgeon pin	PW01-01791
47	Piston	PW01-01792
48	Oil ring	PW01-01793
49	Second compression ring	PW01-01794
50	Top compression ring	PW01-01795
51	Cylinder cover bolt	PW01-01796
52	Cylinder Cover Bolt Gasket	PW01-01797
53	Cylinder Cover Gasket	PW01-01798
54	Breather tube	PW01-01799
55	Cylinder head cover	PW01-01800
56	Cylinder head cover gasket	PW01-01801
57	Rocker Nut	PW01-01802
58	Rocker Adjusting Nut	PW01-01803
59	Rocker Arm	PW01-01804
60	Rocker Bolt	PW01-01805

Item	Description	SIP Code
	4 - Engine..cont.	
61	Push-Rod Frame	PW01-01806
62	Exhaust Valve Cap	PW01-01807
63	Exhaust Valve Spring Retainer	PW01-01808
64	Intake Valve Spring Retainer	PW01-01809
65	Valve Spring	PW01-01810
66	Valve leader seal	PW01-01811
67	Stud bolt M8×32	PW01-01812
68	Nut M8	PW01-01813
69	Exhaust Pipe Gasket	PW01-01814
70	Cylinder Head	PW01-01815
71	Exhaust Pipe	PW01-01816
72	Muffler	PW01-01817
73	Muffler Cover	PW01-01818
74	Flange Bolt M6×8	PW01-01819
75	Exhaust Valve	PW01-01820
76	Intake Valve	
77	Cylinder Head Gasket	PW01-01821
78	Push-rod	PW01-01822
79	Tappet	PW01-01823
80	Flange Bolt M6×12	PW01-01824
81	Cylinder Head Pin φ12×20	PW01-01825
82	Cylinder Head Bolt M10×80	PW01-01826
83	Governor Shaft Seal	PW01-01827
84	HT Coil & Lead	PW01-01828
85	Flange Bolt M6×25	PW01-01829
86	Spark Plug	PW01-01830
87	Carburettor Setting Bolt	PW01-01831
88	Carburettor Insulator Gasket	PW01-01832
89	Carburettor Insulator	PW01-01833
90	Carburettor Gasket	PW01-01834
91	Carburettor	PW01-01835

Item	Description	SIP Code
	4 - Engine..cont.	
92	Air Filter Gasket	PW01-01836
93	Flange Nut M6	PW01-01837
94	Air Filter press plate	PW01-01838
95	Air Filter	PW01-01839
96	Charge winding	PW01-01840
97	Starter Motor	PW01-01841
	5 - Alternator	
98	Rotor	PW01-01842
99	Stator	
100	Flange Bolt M6×12	PW01-01843
101	Muffler Support Bracket	PW01-01844
102	Stator Bolt	PW01-01845
103	Carbon Brush	PW01-01846
104	Wiring Terminal Block	PW01-01847
105	Bolt M5×12	PW01-01848
106	Back Cover	PW01-01849
107	Motor Bracket	
108	Rotor Bolt	PW01-01850
109	AVR Assembly	PW01-01851