




25400—SIP Digital Inverter Generator


Exploded Drawing & Parts List

TD007

Issue v2

Date: 28/04/22

Ref. No	Description	SIP Part No.	Ref. No	Description	SIP Part No.
1.	Left Case assy	PW01-02500	12.	Seal Rubber	PW01-02511
2.	Right case assy	PW01-02501	13.	Muffler Cover	PW01-02512
3.	Bolt M5×12	PW01-02502	14.	Screw bolt M6×20	PW01-02513
4.	Hand pull plate fender	PW01-02503	15.	Rubber Support Column	PW01-02514
5.	ST4.2X16	PW01-02504	16.	Panel Clip insert	PW01-02515
6.	Stop button	PW01-02505	17.	Screw bolt M6×25	PW01-02516
7.	ST4.8X16	PW01-02506	18.	Cross recessed bolt M5×18	PW01-02517
8.	Cover Left, Case	PW01-02507	19.	Nut M5	PW01-02518
9.	Cover Left, Case	PW01-02508	20.	Oil switch	PW01-02519
10.	Fuel tank decoration cover	PW01-02509	21.	Oil sight bubble	PW01-02520
11.	Cover, plug	PW01-02510			



25400—SIP Digital Inverter Generator

Exploded Drawing & Parts List


TD007

Issue v2


Date: 28/04/22


Ref. No	Description	SIP Part No.	Ref. No	Description	SIP Part No.
1.	Front cover seat panel	PW01-02521	11.	DC socket	PW01-02531
2.	ST4.2X16	PW01-02522	12.	Panel Decals	PW01-02532
3.	Plate, Front cover	PW01-02523	13.	Socket	PW01-02533
4.	Screw ST4.2×12	PW01-02524	14.	Nut M4	PW01-02534
5.	On/Off switch	PW01-02525	15.	Screw M4×12	PW01-02535
6.	Bolt M6×16	PW01-02526	16.	Panel Decals	PW01-02536
7.	Gasket Ø6.5×Ø12×1	PW01-02527	17.	Screw bolt M5×12	PW01-02537
8.	Nut M6	PW01-02528	18.	Indicator light board	PW01-02538
9.	Reset switch	PW01-02529	19.	Cable	PW01-02539
10.	Nut M7	PW01-02530			

Ref. No	Description	SIP Part No.
1.	Tank	PW01-02540
2.	Filter mesh assy	PW01-02541
3.	Tank Cap	PW01-02542
4.	Fuel Filter	PW01-02543
5.	Clamp $\phi 10$	PW01-02544
6.	Fuel Tube	PW01-02545
7.	Clamp $\phi 8$	PW01-02546
8.	Fuel Switch	PW01-02547
9.	Screw ST4.2X16	PW01-02548
10.	Fuel tube 2	PW01-02549



Ref. No	Description	SIP Part No.
1.	Inverter Assy	PW01-02550
2.	Inverter assy fixed bracket	PW01-02551
3.	Screw bolt M6×16	PW01-02552
4.	Nut M6	PW01-02553
5.	Anti Vibration feet	PW01-02554
6.	Bracket	PW01-02555
7.	Engine mounting bracket	PW01-02556
8.	Screw bolt M6×16	PW01-02557





25400—SIP Digital Inverter Generator

Exploded Drawing & Parts List


TD007

Issue v2


Date: 28/04/22

Ref. No	Description	SIP Part No.	Ref. No	Description	SIP Part No.
1.	Fan cover	PW01-02558	9.	Rear air guide cover sealant	PW01-02566
2.	Self tapping screw ST4.8X16	PW01-02559	10.	Engine oil port sealant block	PW01-02567
3.	Right cover	PW01-02560	11.	Oil separator	PW01-02568
4.	Left cover	PW01-02561	12.	Hex flange combination bolt M5×16	PW01-02569
5.	Pull cord assembly	PW01-02562	13.	Clamp 10φ	PW01-02570
6.	Screw bolt M5 X 12	PW01-02563	14.	Exhaust pipe 1	PW01-02571
7.	High voltage ignition	PW01-02564	15.	Exhaust pipe 2	PW01-02572
8.	Self tapping screw ST4.8X25	PW01-02565	16.	Oil and gas separator O-ring	PW01-02573


Ref. No	Description	SIP Part No.
1.	Self tapping screw ST4.8X16	PW01-02574
2,3,4	Air filter body, & element kit	PW01-02575
5.	Hexagon flange nut M5	PW01-02576
6.	Self tapping screw ST4.2X12	PW01-02577




Ref. No	Description	SIP Part No.
1.	Muffler	PW01-02581
2.	Bolt M6×45	PW01-02582
3.	Bolt M6×60	PW01-02583
4.	Gasket, muffler	PW01-02584
5.	Tube, muffler	PW01-02585
6.	Hex combination bolt M5×22	PW01-02586
7.	Gasket, muffler	PW01-02587



Ref. No	Description	SIP Part No.
1.	Magneto	PW01-02588
2.	Bolt M5×25	PW01-02589
3.	Bolt M5×10	PW01-02590
4.	Trigger	PW01-02591
5.	Magneto cover	PW01-02592
6.	Nut M10	PW01-02593
7.	Fan impeller	PW01-02594
8.	Start Cup Holder	PW01-02595
9.	Bolt M6×16	PW01-02596
10.	Start Cup	PW01-02597
11.	Bolt M6×12	PW01-02598





25400—SIP Digital Inverter Generator

Exploded Drawing & Parts List

TD007

Issue v2

Date: 28/04/22

Ref. No	Description	SIP Part No.	Ref. No	Description	SIP Part No.
1.	Cylinder cover	PW01-02599	13.	Stator limit connection block	PW01-02611
2.	Hexagon socket combination bolt M5×18	PW01-02600	14.	Positioning pin	PW01-02612
3.	Gasket	PW01-02601	15.	Bolt M5×55	PW01-02613
4.	Upper rocker arm	PW01-02602	16.	Adiabatic Gasket1	PW01-02614
5.	Tappet	PW01-02603	17.	Adiabatic Plate ,carburettor	PW01-02615
6.	Upper rocker pin	PW01-02604	18.	Adiabatic Gasket2	PW01-02616
7.	Valve Keeper	PW01-02605	19.	Hexagon socket combination bolt M5×18	PW01-02617
8.	Valve spring	PW01-02606	20.	Carburettor	PW01-02618
9.	Injection head bolt M5X5	PW01-02607	21.	Clamp φ8	PW01-02619
10.	Valve seal	PW01-02608	22.	Hexagon socket combination bolt M5×25	PW01-02620
11.	Plug	PW01-02609	23.	Timing cover	PW01-02621
12.	Cylinder block	PW01-02610	24.	Gasket 3	PW01-02622

25400—SIP Digital Inverter Generator

Exploded Drawing & Parts List

TD007

Issue v2

Date: 28/04/22

Ref. No	Description	SIP Part No.	Ref. No	Description	SIP Part No.
25.	Camshaft limit bushing	PW01-02623	37.	Piston pin circlip	PW01-02635
26.	Camshaft	PW01-02624	38.	Piston pin	PW01-02636
27.	Small rocker limit bushing	PW01-02625	39.	Piston	PW01-02637
28.	Lower rocker arm	PW01-02626	40.	Dipstick	PW01-02638
29.	Lower rocker shaft	PW01-02627	41.	Crankshaft connecting rod assembly	PW01-02639
30.	Camshaft pin	PW01-02628	42.	Crankshaft oil seal	PW01-02640
31.	Intake valve	PW01-02629	43.	Oil Pipe	PW01-02641
32.	Exhaust valve	PW01-02630	44.	Clamp $\phi 13$	PW01-02642
33.	Top Piston ring	PW01-02631	45.	Middle box	PW01-02643
34.	2nd Piston ring	PW01-02632	46.	Valve	PW01-02644
35.	Oil ring	PW01-02633	47.	Reed Valve	PW01-02645
36.	Backing ring	PW01-02634	48.	Hexagon socket bolt M6×20	PW01-02646

Ref. No	Description	SIP Part No.	Ref. No	Description	SIP Part No.
49.	Hexagon socket bolt M6×45	PW01-02647	54.	Oil Alarm / Sensor	PW01-02652
50.	Lower Housing	PW01-02648	55.	Hex combination bolt M6×16	PW01-02653
51.	Hexagon socket bolt M5×25	PW01-02649	56.	Gasket $\phi 10 \times \phi 6.5 \times 1$	PW01-02654
52.	Gasket 4	PW01-02650	57.	Hex combination bolt M5×12	PW01-02655
53.	Hexagon socket bolt M6×10	PW01-02651			