

# Guide to Assembly & Usage

## BiG200 Shelving With Correx Plastic Bin Kits



### Information

If in doubt, contact the supplier



Read this guide thoroughly before commencing assembly and retain for future reference



Before commencing assembly, unpack carefully and check that all components ordered are included



Assembly should be undertaken by a minimum of two competent people



**Tools:**  
Rubber mallet



Assess for floor fixing. Tall narrow bays may require this to ensure stability



We recommend products over 2000mm high are fixed to the wall where possible



### Caution

During assembly, ensure to:



Take care during assembly and in use, particularly when lifting or stretching & when using tools



Wear appropriate safety clothing – protective gloves and footwear are recommended



Build on a suitable level floor, which is strong enough to support the load and allow adequate working space



Dispose of packaging materials responsibly



### Warning

Rules for the safe use of shelving:



Ensure these instructions are retained for reference and that users are aware of the rules for safe use



Never climb on the structure or stand on the shelving



Do not lean or support ladders, steps, or other objects against shelving



Always use safety steps to reach high shelves



Do not use in damp or wet conditions



Load heavy items on the lower shelves & lighter items on the higher shelves




This product is designed for hand loading only



Ensure that the maximum load carrying capacities are not exceeded



Please refer to the loading information supplied for details



### COMPONENT CHECK LIST

Component	Quantity
<b>A</b> Upright	4
<b>B</b> Front & Back Beam	2 per level
<b>C</b> Side Beam	6
<b>D</b> Chipboard Decks	1 per level
<b>E</b> Plastic Foot	4

### LOADING INFORMATION

#### BiG200 SHELVING WITH CORREX PLASTIC PARTS BINS

For any other layouts, please refer to your supplier for detailed loading capacities

#### Shelf load capacities

Maximum permitted shelf capacities are based on UDL<sup>1</sup>. Please note that the bay capacity may limit the maximum load per shelf.

BiG200 Shelving With Correx Plastic Bin Kits	
Shelving Dimensions mm	Capacity UDL <sup>1</sup> per shelf
1600h x 915w x 305d	70kg
1600h x 1200w x 305d	70kg
1600h x 915w x 455d	80kg
1600h x 1200w x 455d	80kg


IF YOU ARE IN ANY DOUBT REGARDING LOAD CAPACITIES, PLEASE CONTACT YOUR SUPPLIER

<sup>1</sup>UDL = Uniformly Distributed Load


If you have any missing components please take note of the part name and contact your supplier

# Assembly - BiG200 Shelving With Correx Plastic Bin Kits


- 1** Attach plastic feet **E** to bottom of uprights **A** ensuring the keyhole in the upright is the same way up as the image below.




- 2** Connect the two uprights together using a side beam **C** leaving 4 clear keyhole spacing at the bottom of the uprights **A**.



- 3** Create two side frames by adding side beams **C** to the uprights **A** as per the below picture. Ensuring side beams are at the same height on each frame. Knock into place using a rubber mallet.



- 4** Connect the two side frames together with front & back beams **B** at the same height of the lowest side beams **C**.



- 5** Add a chipboard deck **D** to create the first level.



- 6** Repeat steps 3 and 4 to create remaining levels. Leaving 2 clear keyhole spacing between beams.



- 7** On adding the chipboard **D** to the 4th and 9th level, the side beams **C** will need to be removed to allow room for the chipboard to be inserted. Simply knock them out of place, add the chipboard and reconnect the side beams afterwards.

