Guide to Assembly & Usage

BiG400 Mobile Packing Bench



Information

If in doubt, contact the supplier



Read this guide thoroughly before commencing assembly and retain for future reference



Before commencing assembly, unpack carefully and check that all components ordered are included



Assembly should be undertaken by a minimum of two competent people



Tools - Large rubber mallet, spanners 10mm, 13mm and 15mm



Caution

Assemble according to these instructions and maintain properly



Take care during assembly and in use, particularly when lifting or stretching & when using tools



Wear appropriate safety clothing



Build on a suitable level floor, which is strong enough to support the load and allow adequate working space



Dispose of packaging materials responsibly



WarningRules for the safe use of Workbenches:



DO NOT use this workbenches for any purpose other than that it was designed for



Not intended to be used as a trolley



Ensure these instructions are retained for reference and that users are aware of the rules for safe use



Never climb on the structure or stand on the Workbench



Do not use in damp or wet conditions



This product is designed for hand loading only



Ensure that the maximum load carrying capacities are not exceeded



Please refer to the loading information

Note: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice.

Important: No liability is accepted for incorrect assembly and/or





OMPONENT CHECK LIST	0
omponent	Quantity
Upright	4
Long 'C' Section Beam	2
Side 'C' Section Beam	2
Front & Back Beam	2
Side Beam	2
Centre Support	1
Plastic Top Caps	4
Chipboard Deck	1 per shel
Castor & Bracket Fixing Set	
	4
Reel Bar Support	2
Reel Bar	
	4


If you have any missing components please take note of the part name and contact your supplier

Assembly - BiG400 Mobile Packing Bench

Attach castors to brackets using four M8 bolts and nuts with a 13mm spanner, placing the M10 washers onto the bolt side of the fixing







Secure uprights (a) into brackets using four M6 bolts and nuts with a 10mm spanner, placing the M6 washers onto the nut side of the fixings



Insert a short side beam into the top two keyholes on the uprights and knock into place using a rubber mallet. Repeat with second short side beam on other side of product




Place front and back 'C' section beams **©** into two remaining top two keyholes on uprights **@** and knock in place with a rubber mallet.



Locate centre support beam fonto the metal studs on the centre of each front and back 'C' section beam for the into place using a rubber mallet.



Add Reel Support Bar 1 at the required level. Repeat with second beam on the other side.



9 Insert Reel Bar (6 into Reel Support Bars









MOBILE WORKBENCHES ARE INTENDED FOR RELOCATION ONLY. REMOVE LOAD BEFORE RELOCATION.
WORKBENCHES ARE SAFE WHEN USED RESPONSIBLY. IF IN DOUBT CONTACT THE SUPPLIER.