

Guide to Assembly & Usage

Multi Position Sheet Platform Truck



Information

If in doubt, contact the supplier



Read this Guide thoroughly before commencing assembly & retain for future reference



Before commencing assembly, unpack carefully & check that all components ordered are included



Tools – 17mm spanner or ratchet, rubber mallet



Caution

During assembly, ensure to:



Take care during assembly & in use, particularly when lifting or stretching & when using tools



Assemble & locate for use on a suitable level floor surface. Allow adequate working space



Wear appropriate safety clothing – protective gloves & footwear are recommended



Dispose of packaging materials responsibly



Warning

Rules for the safe use of trolleys:



Ensure these instructions are retained for reference & that users are aware of the rules for safe use



NEVER CLIMB ON THE STRUCTURE OR STAND ON THE TROLLEY



This product is designed for hand loading only










ENSURE THAT THE MAXIMUM LOAD CARRYING CAPACITIES ARE NOT EXCEEDED



UDL = Uniformly Distributed Load

COMPONENT CHECK LIST

Component	Quantity	Code
Base 	1	WPR BASE
End Beam 	2	SP-WPR2EB
Bolt 	4	SP-WPR2BOLT
Washer 	4	SP-WPR2WASH
320 Rail 	1	SP-WPR2R3
630 Rail 	1	SP-WPR2R6
930 Rail 	1	SP-WPR2R9

WEIGHT CAPACITY

In the vertical

WPR2

500kg UDL

If you have any missing components please take note of the part name, colour and code and contact your supplier

Assembly - Multi Position Sheet Platform Truck

1

Insert an end beam into the holes at the end of the base



2

Secure the end beam by fitting a bolt and washer to each corner



3

Tighten using a 17mm spanner



4

Repeat steps 1-3 with the other end beam



5

Fit a rail into its selected location



6

Tap down using a rubber mallet



7

Repeat with the remaining rails

